

TECH NOTES



Leak Testing the Dräger accuro Bellows Pump

Leak Test Procedure for the Dräger[®] accuro[®] Bellows Pump

1. Insert unopened Dräger Detector Tube[®] into bellows pump.
2. Squeeze bellows pump completely and release.
3. Pump is adequately leakproof if the end-of-stroke indicator has not appeared (i.e., popped up) within 15 minutes.

Quick Leak Test Procedure

1. Insert unopened Dräger Detector Tube into bellows pump.
2. Squeeze bellows pump completely and release.
3. After releasing, the position of the pump body should not change within 1 minute. If you see movement of the bellows after the initial release, the pump should be checked using a time interval of 15 minutes.



Dräger accuro Bellows Pump Cat. No. 800-64000

Notice: This publication is intended for general information only and should not be used as a substitute for reviewing applicable government regulations, equipment operating instructions, or legal standards. The information contained in this document should not be construed as legal advice or opinion nor as a final authority on legal or regulatory procedures.

www.skcinc.com
SKC Inc.
724-941-9701

SKC South
434-352-7149

SKC West
714-992-2780