



863 Valley View Rd, Eighty Four, PA 15330
724-941-9701
skcinc.com

DECONTamination Solution for Isocyanates Cat. Nos. 769-1052, 769-1052D, and 769-1072 Operating Instructions

Limited shelf-life: Check expiration date on packaging.

Cleaning/Decontamination

1. Wet area thoroughly with DECONTamination Solution for Isocyanates. Use an abrasive pad if necessary to enhance penetration.
2. Allow the solution to react for at least 5 minutes. Rinse with water.
3. Recheck the area with Surface SWYPE Cat. No. 769-1022 or 769-1023 and Developing Solution for Isocyanates Cat. No. 769-1062 or 769-1063 to verify decontamination is complete. If contamination is still present, repeat Steps 1 and 2.
4. To decontaminate tools, soak in DECONTamination solution for at least 5 minutes and rinse with water. Recheck with Surface SWYPE to verify decontamination is complete.

SKC Limited Warranty and Return Policy

SKC products are subject to the SKC Limited Warranty and Return Policy, which provides SKC's sole liability and the buyer's exclusive remedy. To view the complete SKC Limited Warranty and Return Policy, go to skcinc.com/warranty.