



863 Valley View Rd, Eighty Four, PA 15330
724-941-9701
skcinc.com

Skin SWYPE for Acid/Base

Cat. No. 769-1036

Operating Instructions

Limited shelf-life: Check expiration date on packaging.

1. Wipe the skin with the cloth portion of the Skin SWYPE pad.
2. Pour ¼ inch of Developing Solution for Acid/Base Cat. No. 769-1066 into the small cup provided.
3. Put the Skin SWYPE pad in the cup, cloth end down and color detection strip up. The developing solution will wick up to the color detection strip and a color change will occur if contamination is present.
4. Allow 3 minutes for color to develop on the strip. The acid detector will change from neutral (orange) color to fuchsia/magenta at pH 3. For caustic exposures, the indicator will change to blue at pH 9.5.

SKC Limited Warranty and Return Policy

SKC products are subject to the SKC Limited Warranty and Return Policy, which provides SKC's sole liability and the buyer's exclusive remedy. To view the complete SKC Limited Warranty and Return Policy, go to skcinc.com/warranty.